



**P/N: INS-ABP-2016**  
**KIT-PANEL-BACK-20X16**

**Installation Instructions:**

The kit consists of the following components

- Item A) Panel, 20x16x08 – QTY (1)
- Item B) Screw, PH #10-32 x 5/16" – QTY (4)

Position the Panel (A) flush against the back of the Base aligned with the bosses and secure with #10-32 X 5/16" Pan Head Screws (B) (x4) into the boss, as shown. Torque to 10-15 in-lbs., using Philips head #2 screwdriver.

Base not included.  
Shown for ref. only

