



## BACK SHELL OPTION "O"



RECOMMENDED CRIMPING INSTRUCTIONS OPTION "0"

- 1. BUILD UP WIRE OD TO min Ø7.0mm W/ HEATSHRINK
- 2. USE 0.305" HEX CRIMP TOOL \*MAY NOT BE SUITABLE FOR ALL APPLICATIONS

## BACK SHELL OPTION "L"



- BUILD UP WIRE OD TO Ø8.3mm-Ø8.5mm W/ HEATSHRINK
- USE 0.350" HEX CRIMP TOOL \*MAY NOT BE SUITABLE FOR ALL APPLICATIONS

## Roks Compliant



DRAWN:

M. SIGMON

DATE:

08/12/2016

UNITS = inch [mm]

DO NOT SCALE FROM DRAWING

REV

or	$C_{C}$	om	g
•	•	<i>-</i>	$\sim$
	or	orCo	orCom

SCALE: SHEET 2 NTS DWG NO. 858-X08-103RLS4