# Replacement Potentiometers for CH Products Flight Simulator Products

## 200-503 Flightstick Pro

X Axis = REPPOT604

Y Axis = REPPOT604

#### 200-568 Combatstick

X Axis = REPPOT604

Y Axis = REPPOT604

## 200-571 Fighterstick

X Axis = REPPOT604

Y Axis = REPPOT604

Z Axis = REPPOT604

# 200-615 Flight Sim Yoke

X Axis = REPPOT604

Y Axis = REPPOT604

Z Axis = REPPOT615

Y Rotation = REPPOT615

X Rotation = REPPOT615

# 200-616 Eclipse Yoke

X Axis = REPPOT604

Y Axis = REPPOT604

Z Axis = REPPOT615

X Rotation = REPPOT615

Y Rotation = REPPOT615

Z Rotation = REPPOT615

## **300-111 Pro Pedals**

X Axis = REPPOT604

Y Axis = REPPOT604

#### 300-122 Pro Throttle

Z Axis = REPPOT604



# 300-133 Throttle Quadrant

X Axis = REPPOT632

Y Axis = REPPOT632

Z Axis = REPPOT632

X Rotation = REPPOT632

Y Rotation = REPPOT632

Z Rotation = REPPOT632