

Number 3320408 Page 1 of 8

Applicant

Tangible Design Team

Japan

Submitted

Prototype of a Smart Radiation Detector "FRISK Radiation Meter" connected to an

Apple iPod Touch.

Software version 1.01, July 26, 2011

Calibration method

The use of the Smart Radiation Detector was according to the manufacturer. For the irradiations with ¹³⁷Cs and ⁶⁰Co gamma-rays a low scatter facility was used. The primary gamma-ray beam was collimated with a conical ring collimator according to ISO 4037-1. For the irradiations with beta rays of ⁹⁰Sr/⁹⁰Y a Buchler secondary standard beta-ray facility was used. The reference point of the Smart Radiation Detector, defined in the geometrical centre of the FRISK box, was positioned at the central axis of the beam. The site of the box with the text FRISK on it was facing the radiation source. During the period of calibration the environmental conditions were as follows: temperature 20 °C, atmospheric pressure between 101 kPa and 102 kPa and

relative humidity 40 %.

Period of calibration

August 4, 2011 until August 9, 2011

Result

The results of the calibration are presented on page 2 until page 5. The reported uncertainty of measurement is based on the standard uncertainty of measurement multiplied by a coverage factor k = 2, which for a normal distribution corresponds to a coverage probability of approximately 95 %. The standard uncertainty of measurement has been determined in accordance with the ISO Guide to the Expression of

Uncertainty in Measurement (GUM).

Traceability

The results of the calibration services of VSL are traceable to primary and/or (inter)nationally accepted measurement standards.

Delft, August 10, 2011

VSL B.V.

Drs. Ing. Cees van 't Wout

Manager Calibrations & Reference

Min

Materials

Frans J.M. Bade

First Metrologist & Supervisor Radiation

Safety

te is consistent with Calibration and Measurement Capabilities (CMCs) that are included in Appendix C of the Mutual Recognition Arrangement (MRA) drawn up by the International Committee for Weights and Measures (CIPM). Under the MRA, all participating institutes recognize the validity of each other's calibration and measurement certificates for the quantities, ranges and measurement uncertainties specified in Appendix C Ut (or details see http://kcdb.bipm.fr).

Metrology

Inst hisseneg 11, 2629 JA Delft (NL) P.O. Box 654, 2600 AR Delft (NL) T +31 15 269 15 00

+31 15 261 29 71

www.vsl.nl

This certificate is issued under the provision that no liability is accepted and that the applicant gives warranty for each responsibility against third parties

Reproduction of the complete certificate is permitted. Parts of this ertificate may only be reproduced after written permission.



Number 3320408 Page 2 of 8

Results

SDD is the distance between the reference point of the source and the reference point of the Smart Radiation Detector.

Beam is the diameter of the radiation beam at the reference point of the Smart Radiation Detector.

The response of the Smart Radiation Detector for gamma rays of ¹³⁷Cs and ⁶⁰Co is given by:

Response =
$$H^*(10) \times M^1$$

The response of the Smart Radiation Detector for beta rays of ⁹⁰Sr/⁹⁰Y is given by:

Response =
$$D_{tissue}(0.07) \times M^{1}$$

Where:

M is the indication of the Smart Radiation Detector obtained from the Apple iPod Touch and corrected for background. The stated uncertainty in the indication M is based on statistical fluctuations only.

 $H^*(10)$ is the reference ambient dose equivalent rate according to ISO 4037-3.

 $D_{tissue}(0.07)$ is the reference absorbed dose to soft tissue at a depth of 0.07 mm.

The value of the quantity absorbed dose to soft tissue at a depth of 0.07 mm corresponds to the quantity H'(0.07) when the unit Gy is replaced by the unit Sv. Soft tissue is taken as 10.1 % H; 11.1 % C; 2.6 % N and 76.2 % O; with a density of 1 g/cm³.

Table 1: First experiment

Threshold:

13 % (default)

Time Range:

30 s (default)

Background:

between 0 cpm and 2 cpm

e SDD	Beam	H*(10)	M	Response
cm	cm	Sv/h	cpm	(µSv/h) / cpm
200	Ø 30	0.58 µ ± 7 %	6 ± 3	0.097
200	Ø 30	6.76 µ ± 5 %	86 ± 7	0.079
200	Ø 30	65.2 µ ± 5 %	898 ± 25	0.073
200	Ø 30	739 µ ± 5 %	10349 ± 50	0.071
200	Ø 30	5.79 m ± 5 %	71999 ± 1000	0.080
	200 200 200 200 200	cm cm 200 Ø 30 200 Ø 30 200 Ø 30 200 Ø 30 200 Ø 30	cm cm Sv/h 200 Ø 30 0.58 μ ± 7 % 200 Ø 30 6.76 μ ± 5 % 200 Ø 30 65.2 μ ± 5 % 200 Ø 30 739 μ ± 5 %	cm cm Sv/h cpm 200 Ø 30 $0.58 \mu \pm 7 \%$ 6 ± 3 200 Ø 30 $6.76 \mu \pm 5 \%$ 86 ± 7 200 Ø 30 $65.2 \mu \pm 5 \%$ 898 ± 25 200 Ø 30 $739 \mu \pm 5 \%$ 10349 ± 50





Number 3320408 Page 3 of 8

Table 2: Second experiment

Threshold:

13 % (default)

Time Range:

30 s (default)

Background:

between 0 cpm and 2 cpm

Background. Detween a opin and 2 opin				
SDD	Beam	H*(10)	М	Response
cm	С	Sv/h	cpm	(µSv/h) / cpm
200	Ø 30	0.58 µ ± 7 %	8 ± 6	0.073
200	Ø 30	6.76 µ ± 5 %	95 ± 6	0.071
200	Ø 30	65.2 µ ± 5 %	934 ± 35	0.070
200	Ø 30	739 µ ± 5 %	10299 ± 200	0.072
200	Ø 30	5.79 m ± 5 %	72499 ± 500	0.080
200	Ø 30	35.3 µ ± 5 %	463 ± 32	0.076
200	Ø 30	317 µ ± 5 %	3999 ± 100	0.079
	SDD cm 200 200 200 200 200 200 200	SDD Beam cm c 200 Ø 30 200 Ø 30	SDD Beam H*(10) cm c Sv/h 200 Ø 30 0.58 μ ± 7 % 200 Ø 30 6.76 μ ± 5 % 200 Ø 30 65.2 μ ± 5 % 200 Ø 30 739 μ ± 5 % 200 Ø 30 5.79 m ± 5 % 200 Ø 30 35.3 μ ± 5 %	SDD Beam $H^*(10)$ M cm c Sv/h cpm 200 Ø 30 $0.58 \mu \pm 7 \%$ 8 ± 6 200 Ø 30 $6.76 \mu \pm 5 \%$ 95 ± 6 200 Ø 30 $65.2 \mu \pm 5 \%$ 934 ± 35 200 Ø 30 $739 \mu \pm 5 \%$ 10299 ± 200 200 Ø 30 $5.79 m \pm 5 \%$ 72499 ± 500 200 Ø 30 $35.3 \mu \pm 5 \%$ 463 ± 32

Table 3: Third experiment

Threshold:

13 % (default)


Time Range:

200 s

Background:

between 0 cpm and 2 cpm

Nuclide	SDD	Beam	H*(10)	M	Response
	cm	Cm	Sv/h	cpm	(µSv/h) / cpm
¹³⁷ Cs	200	Ø 30	0.58 µ ± 7 %	background	
¹³⁷ Cs	200	Ø 30	6.76 µ ± 5 %	92 ± 1	0.073
¹³⁷ Cs	200	Ø 30	65.2 µ ± 5 %	895 ± 5	0.073
¹³⁷ Cs	200	Ø 30	739 µ ± 5 %	10200 ± 300	0.072
¹³⁷ Cs	200	Ø 30	5.79 m ± 5 %	70650 ± 150	0.082
⁶⁰ Co	200	Ø 30	35.3 µ ± 5 %	414 ± 2	0.085
⁶⁰ Co	200	Ø 30	317 µ ± 5 %	4050 ± 50	0.078



Background:

9 cpm ± 2 cpm

		1			
Nuclide	SDD	Beam	$D_{tissue}(0.07)$	M	Response
	cm	cm	mGy/h	cpm	(µGy/h) / cpm
⁹⁰ Sr/ ⁹⁰ Y	30	Ø 10	4.46 ± 6 %	30450 ± 550	0.146
⁹⁰ Sr/ ⁹⁰ Y	30	Ø 10	4.46 ± 6 %	30000 ± 1000	0.149



Institute



Number 3320408 Page 4 of 8

Table 4: Linearity and reproducibility

Data adopted from table 1, 2 and 3.

Nuclide	<i>H</i> *(10)	М	М	М
	Sv/h	cpm	cpm	cpm
		First experiment	Second experiment	Third experiment
¹³⁷ Cs	0.58 µ ± 7 %	6 ± 3	8 ± 6	background
¹³⁷ Cs	6.76 µ ± 5 %	86 ± 7	95 ± 6	92 ± 1
¹³⁷ Cs	65.2 µ ± 5 %	898 ± 25	934 ± 35	895 ± 5
¹³⁷ Cs	739 µ ± 5 %	10349 ± 50	10299 ± 200	10200 ± 300
¹³⁷ Cs	5.79 m ± 5 %	71999 ± 1000	72499 ± 500	70650 ± 150
⁶⁰ Co	35.3 µ ± 5 %	not measured	463 ± 32	414 ± 2
⁶⁰ Co	317 µ ± 5 %	not measured	3999 ± 100	4050 ± 50

Nuclide	$D_{tissue}(0.07)$	M	M	М
	mGy/h	cpm	cpm	cpm
		First experiment	Second experiment	Third experiment
⁹⁰ Sr/ ⁹⁰ Y	4.46 ± 6 %	not measured	30450 ± 550	30000 ± 1000





Number 3320408 Page 5 of 8




Figure 1: Results for linearity and reproducibility of the Smart Radiation Detector. Data adopted from table 4.





Number 3320408 Page 6 of 8

Notes

According to the recommendations of ISO and ICRU it's necessary that the Smart Radiation Detector is scaled in the quantity Ambient Dose Equivalent Rate, symbol $H^*(10)$ with the unit Sv/h, when used as a radiation survey monitor for gamma- and x-rays.

References

International Standard ISO 4037-1, 1997. X and gamma reference radiation for calibrating dosemeters and doserate meters and determining their response as a function of photon energy.

Part 1: Characteristics of the radiations and their methods of production.

International Standard ISO 4037-2,1997. X and gamma reference radiation for calibrating dosemeters and doserate meters and determining their response as a function of photon energy.

Part 2: Dosimetry for radiation protection over the energy ranges 8 keV to 1.3 MeV and 4 MeV to 9 MeV.

International Standard ISO 4037-3, 1999. X and gamma reference radiation for calibrating dosemeters and doserate meters and determining their response as a function of photon energy.

Part 3: Calibration of area and personal dosemeters.





Number 3320408 Page 7 of 8




Figure 2: Smart Radiation Detector "FRISK Box" with the 9 V power supply (black box) connected to an Apple iPod Touch.






Figure 3: View of the control desk.



Number 3320408 Page 8 of 8



Figure 4: Set-up for irradiation with gamma-rays of ¹³⁷Cs and ⁶⁰Co.




Figure 5: Set-up for the irradiation with beta-rays of ⁹⁰Sr/ ⁹⁰Y.

